

3x3 ZiggyMarquee Setup Instructions



1. Remove from bag



2. Place feet on stable ground



3. Extend frame to extended size of 1.2m x 1.2m



4. Lay canopy over top of frame




5. Align the canopy top over the frame corners and place Velcro on all 4 corners (none on top piece)



6. Make sure canopy is flush on hardware



7. Lift inside pole in center to extend frame completely



8. Secure top with tabs



9. Lift the 2 adjacent outer legs and slide out the inner legs until the snap button locks into the hole in the outer leg



10. Repeat on opposite legs; Make sure to do two legs at a time.
*Minimum of two people recommended.



11. Spin winder in the center of the frame to completely tighten tent



12. Canopy kit assembled



13. Apply fullwall to top Velcro strip inside canopy



14. Secure to side poles with Velcro strips (x4 per pole)



15. Fullwall assembled



16. Attach each side of pole to pole collar; Secure with Velcro strip (x3)



17. Halfwall assembled

